

Quick Start Instructions

Setup Instruction Sheet for the Craft ROBO (CC100-20)











Thank you for purchasing the Graphtec Craft ROBO.

This quick start instruction sheet outlines the procedure for setting up your machine. After setup, refer to the "Quick Application Guide" included with the Craft ROBO to learn how to use it.

The user's manuals for the main unit and software are available in PDF format on the CD-ROM supplied with the Craft ROBO. Refer to these manuals for details on the Craft ROBO functions.


STEP 1 Check All the Included Items

This product comes with the following standard items. Referring to this list, check to confirm that all the items are included.

<input type="checkbox"/> Quick Start Instruction Sheet (this sheet) ...1 copy	
<input type="checkbox"/> Quick Application Guide ...1 copy	
<input type="checkbox"/> Main unit (the Craft ROBO)	<input type="checkbox"/> Media Trial Kit ...1 pack
	
<input type="checkbox"/> Power cable ...1	<input type="checkbox"/> AC adapter ...1
	
<input type="checkbox"/> USB cable ...1	
	
<input type="checkbox"/> Blade holder (with blade adjustment cap) ...1	<input type="checkbox"/> Blade adjustment cap ...2
	
<input type="checkbox"/> Ball-point pen holder ...1	<input type="checkbox"/> Standoff ring ...1
	
<input type="checkbox"/> Craft ROBO Software Package CD-ROM ...1	
	

How to Connect the Power Cable


Referring to the diagram shown below, connect the power cable to your machine in the sequence (1) to (3).




STEP 2 Install the Software

First of all

1. Check that the Craft ROBO is not connected to your computer. Start Windows, and then insert the CD-ROM included with your Craft ROBO into the CD drive of your computer.




2. The Craft ROBO Start window is displayed after a short interval.



If it is not displayed, select "Specify File Name to Execute" from the Windows Start menu, execute the MultiSetup.exe program on the CD-ROM, and then click the OK button.

MultiSetup.exe



3. Click "Install Craft ROBO Software and Driver" in the Craft ROBO Start window to launch the installer. All the required software will be successively installed by "Install Craft ROBO Software and Driver". Follow the displayed screens to complete the installation.



Click here



STEP 3 Connect the Craft ROBO to a PC

Using the Craft ROBO for the first time

4. When the following message is displayed, use the USB cable to connect the Craft ROBO to your computer. A wizard and the Help menu will be displayed. Follow the instructions to complete the setup.



When the software installation has been completed, it may be necessary to reboot Windows. In this case, follow the instructions for rebooting. After rebooting, and when the USB cable is used to connect the Craft ROBO to your computer, Windows will automatically recognize the Craft ROBO. If the "Search for New Hardware" wizard is displayed, select "Install the software automatically (Recommended)".


5. This completes the installation of the software. You can now start using your Craft ROBO. Close the Craft ROBO Start window.

The ROBO Master software is installed during the software installation process. This software will help you to create stickers, cut text on vinyl film, or create pop-up greeting cards.

Setup of the Craft ROBO main unit is now complete. Use the Media Trial Kit to learn basic methods of using the Craft ROBO.


Craft ROBO Operation Manual

1 The Craft ROBO has the two functions shown below.




Mounting the Blade holder


Confirm that you have the following items supplied with your Craft ROBO.




install a blade adjustment cap.




Referring to the Picture shown below, firmly mount the blade holder in the Craft ROBO.



The most suitable blade adjustment cap is automatically displayed when the Media Type is selected in the Craft ROBO Controller.




Learn how to use it with the Media Trial Kit.



Mounting the Ball-point Pen

Referring to the Picture shown below, mount a ball-point pen in the Craft ROBO. When using a ball-point pen, select "Pen" for "Media Type" in the Craft ROBO Controller.



Caution:

Be particularly careful with the cutter blade when changing the blade adjustment cap or installing the blade holder to the Craft ROBO.

NOTE: Graphtec does not guarantee the cutting quality when non-genuine Craft ROBO media is used. Using non-standard media may void the warranty.


2 Load a Sheet for Cutting or Test Plotting

Load a sheet in the Craft ROBO


Note before using

Do not load media without a protective liner, or perform a cutting operation when there is no media loaded, as this will damage the cutting mat.


Press the Standby switch, and confirm that the LED lamp lights.



While making sure that the sheet is straight, align it with the guide line.



Turn the feed knob counterclockwise to feed the sheet. Continue feeding the sheet until its top edge is aligned with the cutting mat as shown below.




Setup is complete

Note: Turn the feed knob to remove the sheet.

When cutting has been completed, press the Standby switch and confirm that the LED lamp goes out.

Notes on Loading Media in the Craft ROBO


Sheet Width: 200 mm up to a maximum of 260 mm



When loading an A4-size sheet, align it with the guide line.

To cut a sheet smaller than A4 size or a sheet without a protective liner, affix it to the carrier sheet included with the Craft ROBO before performing cutting.

To cut A4-size media, peel off the protective liner from both edges of the carrier sheet prior to use.



The standoff ring should be used when cutting a sheet that has been affixed to the carrier sheet.

